



# T & E Pumps Parts Breakdown for 114RW

Item Number	Name	Quantity
EP002	Small Endplate	2
B002	Bushings - Inner plate	4
B25	Bushing - 2.5"	3
H002	Hold Down Ring c/w Flats	3
GN002	Grease Nipple Adapters	3
CC001	Combo cap	3
CC002	Combo cap ends	3
NSK AELS206-102	1.125 Insert Ball bearing	3
AR-1592-EO	Seal	6
MDYE 3/8 plug	3/8 plug scre	2
GN001	Grease Nipples	4
G001-64	End Cap Gaskets	4
G002A-32	Durabla Gasket Small	3
MDP12-112	1/2 x 1 1/2 Dowell Pin	4
MCSH8C12-134	1/2 x 1-3/4 GR8 Bolt	24
M008-4100	Keystock for 7.25 & 7.5" gears	2
I003-18.5	18.5" Idler for 4100 & 4000R	1
OO35-7147	O-ring	3
W001	Washer - Aluminum	3
I004-26	Complete Input Assembly - 26"	1
SG7.500	Steel Gears - set-7.500x5.125	1
WP001	Wear Plates -Small	2
HOU00750RC	4000R - T&E Cast Housing	1
G002A-64	Durabla Gasket-Small	3